

ultra fast. ultra strong. ultrasonic.

Sonosystems[®]

SCHUNK SONOSYSTEMS

ULTRASONIC WELDING FOR BATTERY APPLICATIONS



ABOUT US ultra fast. ultra strong. ultrasonic.

Our 400 employees worldwide develop and produce our innovative ultrasonic welding equipment - and together with our representatives we are always close to our customers. In addition to our headquarters in Wettenberg (Germany), we have locations in Boston (USA), Toluca (Mexico), Kenitra (Morocco), Taicang (China), Ansan City (South Korea) and Yokohama (Japan). Furthermore we have a worldwide sales and service network.

APPLICATION AREAS



WIRE HARNESS

- ¬ Wire Wire | Wire Terminal
- ¬ X-/Y-Splices
- ¬ Cascade | Mixed-Connections
- ¬ Ground and high current contacts
- ¬ Busbars | Flat Flex Wires
- High Voltage Applications



POWER ELECTRONICS

- ¬ IGBT Modules
- ¬ IPM Modules
- ¬ Cell contacting Systems
- ¬ Signal Terminals to substrates



SERVICE

- Technical advice and support
- ¬ Process development and integration
- ¬ Software development
- ¬ Training system



BATTERY


- ¬ Battery modules ¬ Li-lon Technology
- ¬ Capacitors
- ¬ Anode/cathode connections
- Copper/Tab connections

COOLING TECHNOLOGY

- ¬ Copper tubes for refrigeration circuits
- ¬ Capillary tubes for thermostats
- ¬ EX-certified

BATTERY APPLICATIONS

In battery technology, Li-ion cells have become widely accepted today. Schunk Sonosystems covers the complete range of applications from cell production to interconnection and battery contacting. No matter whether you use your mobile phone in the morning, drive to work in your e-car or boot up your laptop: Metal welds on Schunk Sonosystems Li-Ion cells reliably accompany you all day long. The range of applications for Li-ion cells extends from ultrasonic welding of thin-walled Al and Cu foils to welding of high-current contacts and wire elements.







BatteryWelder20kHz

- ¬ Suitable for welding large cells
- ¬ Robust frame construction
- ¬ Modular machine design enables integration into automated production lines
- ¬ Quick-change system for exchanging the oscillation unit
- ¬ Optimum accessibility of the welding area
- ¬ Extensive log file contains all process data


THE **MODULAR BATTERY** WELDING SYSTEM FOR EVERY NEED

BATTERY APPLICATIONS | BW20

COMPACT-III CONTROLLER

- ¬ Power: 3kW | 4 kW | 6 kW | 9 kW
- ¬ Frequency: 20 kHz
- ¬ PC & PLC
- ¬ Various operating modes can be selected via key switch, the operation mode is additionally password protected
- ¬ Controlled cooling of the converter and the sonotrode
- ¬ Networkable





VARIOUS MODULAR OPTIONS AVAILABLE. DIFFERENT OSCILATIONSYSTEM TYPES, DIFFERENT CYLINDER TYPES.








BATTERY APPLICATIONS | DS35-B

DS35-B

- ¬ Suitable for supercapacitors and filigree applications
- ¬ The precise mechanical design is designed for an operating cycle of millions of welds
- ¬ Can be easily integrated into production lines
- ¬ Simple and precise adjustment of the upper and lower end stops for the sonotrode



SPECIFICATIONS


	BW20	DS35-B
STROKE	55 mm	20 mm
GENERATOR POWER	4 kW 6 kW 9 kW	0,9 kW 1,2 kW
FREQUENCY	20 kHz	35 kHz
MAXIMUM PRESSING FORCE	> 4000 N	575 N
VOLTAGE SUPPLY	3 x 400 V, N, PE	1 x 230 V, N, PE
COMPRESSED AIR	6 bar	6 bar
DIMENSIONS (MM) L X B X H	615 x 240 x 560	270 x 120 x 230
WEIGHT (KG)	80 (without controller)	50

USC-4 CONTROLLER

- ¬ Power: 3 kW, 1 kW (DS35-B)
- ¬ Frequency: 20 kHz, 35 kHz (DS35-B)
- ¬ PC & PLC
- Various operating modes can be selected via key switch, the operation mode is additionally password protected
- ¬ Networkable









OUR LOCATIONS

GERMANY

Schunk Sonosystems GmbH +49 641 803 0 sonosystems@schunk-group.com USA

Schunk Sonosystems North America +1 978 658-9400 sonosystems.usa@schunk-group.com

MOROCCO Schunk Sonosystems Maroc +212 660 695749 sonosystems.maroc@schunk-group.com

CHINA Schunk Sonosystems China +86 512 53443110 sonosystems.china@schunk-group.com

JAPAN Schunk Carbon Technology Japan K.K. +81 45 470 2339 sonosystems.japan@schunk-group.com SOUTH KOREA Schunk Carbon Technology Ltd +82 31 491 2722 dong-gyun.choi@kr.schunk-group.com



All our local support teams you find on our webpage www.schunk-sonosystems.com

Schunk Sonosystems GmbH Hauptstraße 95 35435 Wettenberg Germany













+49 641 803 0



sonosystems@schunk-group.com